

TO FIGURE THE NUMBER OF RISERS REQUIRED

MEASURE THE DISTANCE FROM YOUR DOCK TO
YOUR BOAT DECK AND DIVIDE BY 8
ROUND TO THE NEAREST WHOLE NUMBER
THIS IS THE NUMBER OF RISERS YOU NEED

CALL US WITH QUESTIONS 888-SALEM15

